DTE5



150983





ENGLISH

Table of contents

1.Safety	
1.1 Key to symbols	
1.2 Safety instructions	
1.3 Proper use	
2. General information	21
2.1 Liability and Warrantees	
2.2 Copyright protection	
2.3 Declaration of conformity	
3. Transport, packaging and storage	22
3.1 Delivery check	22
3.2 Packaging	
3.3 Storage	
ŭ	
4. Technical data	
4.1 Overview of parts	
4.2 Technical specification	24
5. Installation and operation	24
5.1 Installation	
5.2 Operation	
'	
6. Cleaning	27
7 Wasta disposal	28

Bartscher GmbH Franz-Kleine-Str. 28 33154 Salzkotten Germany





Read this instruction manual before using and keep them available at all times!

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

Please keep these instructions and give them to future owners of the device.

1.Safety

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

All persons using the device must follow the recommendations and instructions in this instruction manual.

1.1 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards which could lead to injury.



WARNING!

This symbol highlights dangerous situations which could lead to injury or death.





CAUTION!

This symbol highlights dangerous situations which could lead to light injuries, or damage, malfunction, and/or destruction of the device.



This symbol highlights recommendations and information aimed for effective and trouble-free device operation.

1.2 Safety instructions

- The device can be used by children 8 years and up, as well as by people with disabilities and those with limited experience/knowledge as long as they are under supervision or have been instructed on proper use of the device and its possible dangers. Children should not play with the device. Cleaning and maintenance cannot be performed by children younger than 8 years old and must be done under supervision. Children under the age of 8 years old must be kept away from the device and its power cord.
- Never leave the device unattended when in use.
- · Only use the device indoors.
- The device must be operated in correct and safe technical condition only. In case of operational problems disconnect the device from the power supply (pull the plug from the socket) and contact the service company.
- Prevent access of children to the package materials like plastic bags and foamed polystyrene elements. Suffocation hazard!

Bartscher

- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. Do not attempt to repair the device yourself.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.



DANGER! Electric shock hazard!

To avoid the hazard results please follow the safety instructions below.

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled. Never place the device or other objects on the power cable.
- Do not lay the power cable over carpets or other inflammable materials. Do not cover the cable. Keep away the cable from operating range.



- Check the power cord regularly for damage. Do not use the
 device if the power cord is damaged. If this cable is damaged, it
 must be replaced by customer service or a qualified electrician in
 order to avoid dangers.
- The supply cable must be disconnected from the socket only by pulling the plug.
- Never carry or lift the device by the supply cable.
- In any case do not open the device housing. In case of electrical or mechanical modifications the electric shock hazard will occur.
- Do not use any acid agents and make sure no water ingresses the device.
- Never operate the device with moist hands or standing on wet floor.
- Remove the plug from its socket:
 - when the device is not used,
 - in case of anomalies during operation,
 - before cleaning.



1.3 Proper use

The operational safety of the device is assured only in case of proper use, according to the operation manual.

All technical activities like installation and maintenance must be performed by the qualified service personnel only.

The device is intended for home use or in similar places such as:

- → in kitchens for store or office employees or in similar business areas;
- → in agricultural farms;
- → by guests of hotels, motels and other typical places of accommodation;
- → in Bed and Breakfast facilities.

The drinks dispenser is intended only for keeping cool drinks at low temperatures.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.



2. General information

2.1 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology.



CAUTION!

Read this manual carefully and thoroughly before any operation of the device, and especially before turning it on!

Manufacturer is not liable for any damages or faults caused by:

- violation of advice concerning operation and cleaning;
- use other than designed:
- alterations made by user;
- use of inadequate spare parts.

We reserve the right to make technical changes for purposes of developing and improving the useful properties.

2.2 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

2.3 Declaration of conformity



The device complies with the current standards and directives of the EU. We certify this in the EC declaration of conformity. If required we will be glad to send you the according declaration of conformity.



3. Transport, packaging and storage 3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint. Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.


Packages should be stored under consideration of the following:

- do not store outdoors.
- keep it dry and dust-free.
- do not expose it to aggressive media,
- do not expose it to direct sunlight,
- avoid mechanical shocks and vibration.
- in case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly, if required refresh or renew.



4. Technical data

4.1 Overview of parts



- 1 Lid
- 2 Tank handle
- 3 Tank
- 4 Base
- 5 Spout
- 6 Ventilation ducts

- 7 Green control lamp
- 8 Drip tray and strainer
- 9 ON/OFF switch
- 10 Power cord
- 11 Adapter



4.2 Technical specification

Name	Drinks dispenser DTE5
Code-No.:	150983
Material:	base and lid: chrome nickel steel; tank: polycarbonate
Realization:	Thermoelectric coolingON/OFF switchControl lamp
Tank:	Ø 170 mm, H 280 mm; capacity 5 litres
Dimensions:	W 220 x D 330 x H 520 mm
Power:	60 W / 230 V 50 Hz
Weight:	4.15 kg

We reserve the right to make technical changes!

5. Installation and operation

5.1 Installation

Positioning

 Unpack the device and remove all package materials according to the valid environment protection regulations.



Never remove the rating plate or any warning signs from the device.

- Put the device on a secure, level surface capable of supporting its weight when full.
- Do not put the device in sunny places, as this may have a negative impact on cooling efficiency.
- Do not put the device near open flame, electric ovens, heaters or other heat sources.
- Never put the device at the edge of a table to avoid accidents.
- **Never** put the device in a wet or moist environment.



- Ensure the device's ventilation ducts are not covered in order to ensure optimum cooling. Keep the device at an appropriate distance from all objects.
- Position the device in such way that the plug is easily accessible for quick disconnecting when required.

Connection



DANGER! Electric shock hazard!

The device can cause injuries due to improper installation! Before installation and connecting the local power grid specification should be compared with that of the device (see rating plate). Connect the device only in case of compliance!

Connect the device only to properly installed single socket with protective terminal.

The electrical circuit in the socket must be secured to at least 16A. Only connect the
device directly to the wall socket; do not use any extension cords or power strips.



5.2 Operation

- Before using the device, clean it following the instructions in 6 "Cleaning".
- Ensure the spout is closed, and that the tank, drip tray and strainer are all in their proper places.
- Fill the tank with the desired pre-cooled beverage and place the lid on top.
- First, connect the power cord to the adapter, then connect the device to a grounded, single outlet and turn the drinks dispenser on (ON/OFF switch to "I"). The green control lamp will come on.
- The beverage's low temperature will be maintained for longer due to the cooling element in the base of the device.
- To dispense the cooled beverage, place a glass on the drip tray and press the spout down. Pour the desired amount of beverage, then release the spout.



- The tank may be refilled as needed.
- Remember to regularly empty the drip tray so that it does not overflow.
- If the device is to be unused, set the **ON/OFF** switch to **"O"** and remove the plug from its socket, then disconnect the power cord from the adapter.



6. Cleaning



WARNING!

Before cleaning disconnect the device from the power supply (pull the plug!).

Do not use pressurized water jest for cleaning! Protect the device from the water penetration.

- After use, always clean the device.
- Remove the lid and tank, then wash thoroughly in warm water. Use a disinfectant approved for food service applications and a soft cloth or sponge.
- To clean the spout, run some washing-up water through it, then rinse thoroughly with clean water.
- Wash the drip tray and strainer in warm water with a mild cleaning agent.
- o Rinse with clean water, then dry thoroughly before replacing in the device.
- Wipe the base and its lower surface with a soft, moist cloth. Never immerse the base in water or other liquids.
- o **Never** use harsh cleaners that may scratch the device.
- Dry and polish the device's surface with a soft, dry cloth after cleaning.

Storing the device

 If the device is not used for a long time, clean it according to the above description and store in a dry, clean place, protected against cold, sun and, children.
 Do not place any heavy objects on the device.



7. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



CAUTION



For the disposal of the device please consider and act according to the national and local rules and regulations.

phone: +49 (0) 5258 971-0

fax:

+49 (0) 5258 971-120

Bartscher GmbH Franz-Kleine-Str. 28 33154 Salzkotten Germany