

A120407





ENGLISH Translation of the original instruction manual



Read these instructions before using and keep them available at all times!

1. General information		16
1.1 Information about the instruction	manual	16
1.2 Key to symbols		16
1.3 Liability and Warrantees		17
1.5 Declaration of conformity		17
2.Safetv		18
	device	
2.3 Intended use		19
3. Transport, packaging and storage		20
3.3 Storage		20
4. Technical data		21
5. Installation and operation		22
5.3 Operation		23
6. Cleaning and maintenance		25
6.3 Safety instructions for maintenan	ice	26
7. Possible Malfunctions		27
Bartscher GmbH		
Franz-Kleine-Str. 28		
D-33154 Salzkotten	phone: +49 (0) 5258 971-0	
Germany	fax: +49 (0) 5258 971-120	



1. General information

1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards, which could lead to injury.

Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



CAUTION!

This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



NOTE!

This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.



WARNING! Hot surface!

This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!



1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology. If you have any questions, you should contact the manufacturer.



Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to work with or using it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

1.5 Declaration of conformity

The device complies with the current standards and directives of the EU. We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.



2.Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



CAUTION!

 The device can be used by children 8 years and up, as well as by people with disabilities and those with limited experience/knowledge as long as they are under supervision or have been instructed on proper use of the device and its possible dangers.



- o **Children** should not play with the device.
- Cleaning and maintenance cannot be performed by children younger than 8 years old and must be done under supervision.
- Children under the age of 8 years old must be kept away from the device and its power cord.
- Please keep these instructions and give them to future owners of the device.
- All people using the device should follow the instructions and tips contained in these instructions.
- o Only use the device indoors.

2.3 Intended use



The device has been designed and built for commercial use and should be operated only by qualified personnel in kitchen facilities.

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

The device is not adapted for use with an external timer or remote control.

The electric hot-dog machine is intended only for heating sausages.

Do not use the **hot-dog machine** to:

heat other food products than sausages.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.



3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.


Packages should be stored under consideration of the following:

- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly.
 If required refresh or renew.



4. Technical data

4.1 Overview of parts



- 1) Lid
- (2) Glass cylinder
- 3 Dividing net
- (4) Wire mesh basket
- (5) Perforated bottom plate
- 6 Water tray

- ON/OFF switch with integrated standby light (red)
- Heating control light (green)
- Temperature dial
- 10 Legs
- 1 Housing
- (2) Heating plate



4.2 Technical specification

Name	Electric hot-dog machine	
Code-no.:	A120407	
Construction:	Stainless steel	
Temperature range:	30 ℃ to 100 ℃	
Power:	800 W / 230 V 50 Hz	
Glass cylinder dimensions:	Ø 200 mm, H 240 mm	
Dimensions:	Ø 290 mm, H 420 mm	
Weight:	4.8 kg	

We reserve the right to make technical changes!

5. Installation and operation5.1 Safety instructions



WARNING! Risk of electric shock!

The device must only be connected to a properly installed single socket with protective contact.

Never remove the power cable by pulling the cable itself; always grab the plug housing.

- Never allow the power cable to come into contact with heat sources or sharp edges.
 The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled.
- Never place the device or other objects on the power cable.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.
- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not move or tilt the device when in operation.



- Never use the device with wet or moist hands.
- **Never** leave the device unattended when in use.



WARNING! Hazard via electrical current!

The device can cause injuries due to improper installation!

Before installation the local power grid specification should be compared with that of the device (see type label).

Connect the device only in case of compliance!

Take note of the security advice!

5.2 Installation and connection

- Unpack the unit and remove all packing material.
- Place the unit on top of an even and safe surface which supports the weight of the unit and is not heat sensitive.
- Do not position the unit near open fireplaces, electric ovens/arc furnaces, furnaces/electric heaters or other heat sources.
- Always keep a safe distance of 10 cm to any object, item or wall.
- Never block the unit's ventilation ducts.
- The electrical circuit in the socket must be secured to at least 16A. Only connect the unit directly to a wall socket; do not use any extension cords or power strips.
- Place the unit so that the plug is easily accessible and can be quickly removed from its socket in case of necessity.

5.3 Operation

Before first use!

- Before first use, wash the removable parts of the unit following the instructions given in 6.2 "Cleaning".
- Insert the water tray and fill it with cold drinking water to approx. 3/4 of its capacity.
 Place the glass cylinder on the tray and cover with the lid. Only use the unit with its lid on.
- Connect the unit to a single grounded outlet.
- Turn the unit on via the **on/off** switch. The red integrated control light will come on.

Bartscher

 Turn the temperature dial clockwise to the highest level and heat up the water for a short time. Next, remove the unit's plug from its socket and wait for the unit to cool. After cooling, remove the glass cylinder and empty the water tray.



WARNING! Hot surface!

When in use, some of the unit's elements get very hot. <u>Never</u> touch them with bare hands.

To remove individual elements – glass cylinder, wire mesh basket, dividing net, perforated bottom plate.

Heating sausages

Replace the water tray and fill it with cold drinking water to approx. ³/₄ capacity.
 Place the perforated bottom plate on the tray.



Regularly monitor the level of water. Never use the unit without water!

- Place the glass cylinder on the water tray and place the wire mesh basket inside.
 Fix the dividing net inside the wire mesh basket.
- Place sausages inside the wire mesh basket.
- Place the lid on the glass cylinder.
- Turn the temperature dial clockwise to the highest power level to heat the water. The green heating control light will come on during heating, and will go off when the set temperature has been reached.
- After a short moment, turn the temperature dial counter-clockwise to the desired temperature. Attention! If the temperature is reduced too late, the heat accumulated in the heating plate may cause the water to boil for longer.
- After the desired temperature has been reached, sausages can be kept warm.
- Remove hot sausages from the wire mesh basket as needed.



WARNING! Risk of burns!

Exercise caution when removing the lid from the glass cylinder. Only touch the handle. After removing the lid from the glass cylinder, steam may be released and cause burns to the hands and forearms. To prevent burns, wear safety gloves!



- Use appropriate kitchen equipment such as tongs, forks, etc. to remove sausages.
- If the unit is to remain unused, turn the temperature dial counter-clockwise as far as it
 will go, turn the unit off via the ON/OFF switch and remove the plug from its socket.

6. Cleaning and maintenance6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power supply and has cooled down.
- o Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, never immerse the device, its cables and the plug in water or other liquids.



The device is not suited for direct washing via water jets.

Therefore, you must not use any kind of pressure water jet for cleaning the device!

6.2 Cleaning and descaling

- o Clean the unit regularly.
- Remove the unit's individual parts (glass cylinder, wire mesh basket, dividing net, perforated bottom plate and water tray) and wash them with a soft cloth or sponge and mild cleaning agent.
- Rinse thoroughly in clean water to remove remaining soap. Dry with a soft cloth.



ATTENTION!

- o Wash the water tray at least 2 times daily for sanitation purposes!
- Harmful compounds of water, salt, fats and spices that get into water from sausages create a harsh solution that can even damage metal.
- For these reasons, descale the water tray at least once a day, otherwise it can be subject to corrosion. Use a commercially available descaling substance (according to manufacturer's instructions!) or a mixture of water and vinegar (proportion 3:1).



ATTENTION!

Returns will be refused if the hot-dog machine is not regularly descaled in accordance with these instructions.

Such claims are not covered by warranty!

Bartscher

- Wipe down the unit's housing with a soft, moist cloth.
- For cleaning, only use a soft cloth and never use harsh cleaning chemicals that may damage the unit's surface.
- o After washing, dry and polish the surface with a dry, soft cloth.

6.3 Safety instructions for maintenance

- Inspect the power cable regularly for damage. Never use the device if the cable is damaged. If the power cable is damaged, have an authorised service center or qualified electrician replace it.
- In case of damage or malfunction, please contact your stockist or our customer service centre. Pay attention to the troubleshooting tips in pt. 7.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. Do not attempt to repair the device yourself.



7. Possible Malfunctions

Malfunction	Cause	Solution
The unit is turned on, the temperature dial is set, but the red standby light does not come on and the heating plate does not warm up.	Plug improperly inserted.Safety fuse triggered.Damaged power cord.	 Insert plug properly. Check fuse, connect unit to another outlet. Contact a sales agent.
Temperature dial set, red standby light does not come on, but the heating plate is working.	Damaged control light.	Contact a sales agent.
Temperature is set, red standby light comes on, but the heating plate does not work.	Damaged heating element.	Contact a sales agent.

The above malfunctions are only examples. If any of them or any similar problem occurs that cannot be resolved, disconnect the unit from its power source and contact a service center or a sales agent.



8. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.





For the disposal of the device please consider and act according to the national and local rules and regulations.

fax:

phone: +49 (0) 5258 971-0

+49 (0) 5258 971-120

Bartscher GmbH Franz-Kleine-Str. 28 D-33154 Salzkotten Germany