



200063

Read these instructions before using and keep them available at all times!

**ENGLISH
Translation
of the original instruction manual**

1. General information	16
1.1 Information about the instruction manual	16
1.2 Key to symbols	16
1.3 Liability and Warrantees	17
1.4 Copyright protection	17
1.5 Declaration of conformity	17
2. Safety	18
2.1 General information	18
2.2 Safety instructions for use of the device	18
2.3 Intended use	19
3. Transport, packaging and storage.....	20
3.1 Delivery check.....	20
3.2 Packaging	20
3.3 Storage.....	20
4. Technical data	21
4.1 Overview of parts	21
4.2 Technical specification	22
5. Installation and operation.....	23
5.1 Safety instructions	23
5.2 Installation and connection	24
5.3 Operation	24
6. Cleaning and maintenance	26
6.1 Safety advice	26
6.2 Cleaning and descaling	27
6.3 Safety instructions for maintenance	28
7. Waste disposal	28

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120

1. General information

1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards, which could lead to injury.

Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



CAUTION!

This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



NOTE!

This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.



WARNING! Hot surface!

This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!

1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology. If you have any questions, you should contact the manufacturer.



NOTE!

Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to work with or using it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



NOTE!

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

1.5 Declaration of conformity

The device complies with the current standards and directives of the EU.

We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.

2. Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



CAUTION!

- The device can be used by children **8 years and up**, as well as by people with disabilities and those with limited experience/knowledge as long as they are under supervision or have been instructed on proper use of the device and its possible dangers.

- **Children** should not play with the device.
- Cleaning and **maintenance cannot be performed by children** younger than 8 years old and must be done under supervision.
- **Children under the age of 8 years old** must be kept away from the device and its power cord.
- Please keep these instructions and give them to future owners of the device.
- All people using the device should follow the instructions and tips contained in these instructions.
- Only use the device indoors.

2.3 Intended use

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

The device is not adapted for use with an external timer or remote control.

The device is intended for home use or in similar places such as:

- in kitchens for store or office employees or in other service locations;
- in suburban properties;
- by guests of hotels, motels and other places of accommodation;
- in Bed & Breakfasts.

The water boiler is intended **only** for **cooking and heating** water.

Do not use the water boiler for:

- cooking food products;
- storing and heating flammable, dangerous or ignitable fluids, substances, etc.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



NOTE!

If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly.
If required refresh or renew.


4. Technical data

4.1 Overview of parts



- ① Lid
- ② Lid handle
- ③ Tank handle
- ④ Water tank
- ⑤ Control panel
- ⑥ Base
- ⑦ Spout
- ⑧ Fill level indicator

Control panel



- ⑨ Working light (red)
- ⑩ Heating light (green)
- ⑪ Temperature dial
- ⑫ Temperature indicator
- ⑬ „OFF“ position
- ⑭ **ON/OFF** switch

4.2 Technical specification

Name	Water boiler 28l
Code-No.:	200063
Material:	Tank and lid: stainless steel; base: plastic
Temperature range:	30 °C – 100 °C
Capacity:	28 liters
Power:	2.8 kW / 230 V 50 Hz
Dimensions:	Ø 395 mm, H 640 mm
Weight:	5.4 kg

We reserve the right to make technical changes!

5. Installation and operation

5.1 Safety instructions



WARNING! Risk of electric shock!

The device must only be connected to a properly installed single socket with protective contact.

Never remove the power cable by pulling the cable itself; always grab the plug housing.

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled.
- Never place the device or other objects on the power cable.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.
- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not move or tilt the device when in operation.
- Protect the device from frost and moisture.
- **Never** use the device with wet or moist hands.
- **Never** leave the device unattended when in use.



WARNING! Hazard via electrical current!

The device can cause injuries due to improper installation!

Before installation the local power grid specification should be compared with that of the device (see type label).

Connect the device only in case of compliance!

Take note of the security advice!

5.2 Installation and connection

- Unpack the device and remove all packing material.
- Put the device in a safe place that can support its weight and is not heat sensitive.
- **Never** place the device at the edge of a table to avoid accidents.
- **Never** put the device in a moist or wet area.
- Do not place the device near an open flame, electric heater or other heat source.
- The electrical circuit of the socket must be secured to at least 16A. Only connect the device to a wall outlet; do not use any extension cords or power strips.
- Place the device so that the plug is easily accessible so as to quickly disconnect the device if the need arises.

5.3 Operation

- Before using the device, clean it in accordance with the instructions contained in **6.2 „Cleaning and descaling“**.
- Pour the desired amount of water into the tank (up to the „**MAX**“ indicator).
- Before turning the device on, ensure it contains **a fluid suitable for human consumption**. The device must not hold liquids such as acids, oils, etc.!



WARNING! Danger of burns!

Do not exceed the device's maximum capacity. Overfilling the tank may result in splashing and burns!



CAUTION!

To reduce heating time and save energy, warm water can be used!

- Place the lid on the tank and close it by turning clockwise.

- Connect the device to a single grounded outlet.
- Set the desired temperature between 30 °C – 100 °C using the temperature dial.
- Turn the device on using the **ON/OFF** switch.
- The red working light will come on, then the water will be heated to the set temperature.
- After the set temperature is reached the red working light will go off. The green heating light will come on and the water's temperature will be maintained.



WARNING! Danger of burns!

Never remove the lid while the device is heating!

The steam may cause burns to hands, arms and face!

- Hot water can be used to prepare various beverages (tea, instant coffee, instant soup, etc.).
- Remember that various types of tea brew best at different temperatures. Follow the manufacturer's instructions on the package.
- To pour hot water, place an appropriate container (glass, cup, mug) under the spout. Press the spout lever down and hold it until the desired amount of water is poured.

When finished pouring, release the spout lever and the spout will close automatically.



- Monitor the tank's water level by observing the fill level indicator.



CAUTION!

Monitor the water level regularly and add water as needed.

Never operate the device without water!

- Before adding water turn the device off, carefully remove the cover, then pour in more water.



WARNING! Hot surface!

The water tank gets very hot when in use!

To avoid burns to fingers and hands, do not touch hot surfaces of the device!

When using the device, touch only the handles and switches.

- After you have finished using the device, turn the temperature dial to the „OFF“ position by turning it counterclockwise, then turn the device off using the **ON/OFF** switch and remove its plug from the socket.
- Wait for any remaining water in the tank to cool, then pour it into another container.
- The device is equipped with an **overheating/dry heating** protection function. If the device is accidentally left on with too little or no water, this function will be activated and the device will turn off automatically.
- If the device is to remain unused for a longer period, turn it off via the **ON/OFF** switch, remove its plug from the socket and wait for it to cool.

After cooling, empty the tank and press the **RESET** button at the rear of the device. The device can then later be filled with fresh water and used again.



6. Cleaning and maintenance

6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power supply and has cooled down.
- Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, **never** immerse the device, its cables and the plug in water or other liquids.



CAUTION!

The device is not suited for direct washing via water jets.

Therefore, you must not use any kind of pressure water jet for cleaning the device!

6.2 Cleaning and descaling

Regular cleaning

- Clean the device after every use.
- Wash the inside of the water tank with a mild cleaning agent, then rinse with running water. To clean the water spout, run clean water through it.
- Wash the lid and rinse under running water.
- Clean the device's external surfaces with a moist, soft cloth and mild cleaning agent if needed.
- Always use soft cloths, **never** use abrasive cleaners that could scratch the device.
- After cleaning, dry the device and polish with a soft, dry cloth.

Descaling

- Hard water may cause stone deposits to form in the water tank, lengthening the time needed to heat water and possibly causing damage to the device. **Use filtered water if possible to avoid deposits forming!**



CAUTION!

Failure to conduct regular descaling in accordance with these instructions may void the warranty and result in returns being rejected!

Descal the device regularly!

- We recommend using citric acid or vinegar for ecological descaling. Prepare a mixture of **water with vinegar** (proportion **3:1**) or **water with citric acid (2 table-spoons per 1 liter** of water) and fill the tank. Wait for one hour then boil the water.
- Wait for the device to cool.
- After cooling, pour out the descaling solution and rinse the device **several times** with clean water. Drain the clean water through the pour spout to remove all leftovers.
- Follow manufacturer's instructions if you choose to use a commercially available descaling product.

6.3 Safety instructions for maintenance

- Inspect the power cable regularly for damage. Never use the device if the cable is damaged. If the power cable is damaged, have an authorised service center or qualified electrician replace it.
- In case of damage or malfunction, please contact your stockist or our customer service centre.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**

7. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



NOTE!



For the disposal of the device please consider and act according to the national and local rules and regulations.

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120